



Bluetooth® Earbuds

Model: ITEB-100B (S301)



Instruction Manual

Please read this instruction manual carefully before use and keep for future reference.



BASIC OPERATION & FEATURES


Basic Operation

****You must fully charge the headset before use!****

POWER ON: Press & Hold Power Button.
Listen for *“Power On, Pairing”* audible prompt.

POWER OFF: Press & Hold Power Button.
Listen for *“Power Off”* audible prompt.

Features



NOTE: Parts of the Earbuds are magnetic, metallic material may be effected. **DO NOT** place credit cards or other magnetic storage devices in close proximity to avoid erasing stored information.

PAIRING & CONNECTING TO BLUETOOTH

- Activate the Bluetooth Feature on your device.
- Press & Hold Power Button. Listen for “*Power On, Pairing*” audible prompt. The Bluetooth Connection Indicator light will begin to flash RED & BLUE.
- Select “S301” on your device list. Listen for “*Connected*” audible prompt.
Use password “0000” if required.
- Short press the Power Button to Play/Pause audio.
- Press Volume Up (+) on RIGHT earbud to increase volume. **NOTE:** At max volume you will hear an audible tone. To increase Earbud volume further, raise the volume on your connected device.
Press & Hold to fast forward to the next song.
- Press Volume Down (-) on RIGHT earbud to decrease the volume. Press & hold to rewind current song. Press and hold again to rewind to previous song.
- To disconnect, POWER OFF Earbuds or disconnect your earbuds from your device.

BATTERY CHARGING

When Bluetooth Connection Indicator flashes RED with a beep and low battery audible prompt, battery is low. **NOTE:** Earbuds will power off automatically with continued use.

1. Insert plug of the charger cable into Earbud jack.
2. Plug the charger into a USB port (laptop, AC adapter). Bluetooth Connection Indicator will illuminate RED. A full charge takes approximately 2 hours. RED Indicator light will change to BLUE when Earbuds are fully charged.
3. Disconnect charger from Earbuds and power source. **NOTE:** Fully charged Earbuds can support up to 2-6 hours of talk time and 100-180 hours of standby time. When earbuds are not in use for an extended amount of time, store in a dry place and recharge every two months.

Caution: *The built-in rechargeable battery is not replaceable. Do not remove or replace it, do not throw in the trash or in a fire. Do not dispose device in standard garbage disposal sites. Dispose of device at available Battery Recycling Sites after fully discharging battery. Not doing so may violate local disposal laws and regulations. Please refer to local regulations for proper battery disposal.*

HEADSET FEATURE

To Answer or End a Phone Call:

Apply a short press to the Power / Sync Button to answer, apply the same short press to end call.

To Redial the Last Number:

When in Standby-mode, apply 2 short presses to the Power / Sync Button to redial the last call.

Activate Voice Dialing:

Press and Hold Power / Sync Button until your device alerts you for a voice command.

Call Waiting:

Option 1: Press Power Button once to end the first call and answer the incoming call.

Option 2: Apply a long press to the Power Button to reject the incoming call.

Option 3: Two short presses of the Power Button puts the first caller on hold to answer the incoming call. Two short presses will allow you to switch between callers (with one on hold).

IMPORTANT INFORMATION

FCC Statement

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARRANTY

**Innovative Technology Electronics Corp.
Limited Warranty: 90 Days Labor, One Year Parts**

Innovative Technology Electronics Corp. (IT) warrants the product to be free from “Defects” in materials under normal use for a period of “One Year” from the date of the original purchase. The Warranty is “Not” transferable. IT agrees, within the initial “90 Day” period, to repair or replace the product if it is determined to be defective at “No Charge”. It is further agreed that IT will cover the cost to repair or replace damaged “Parts” only for a total period of “One Year” from the date of the original purchase. The warranty does not cover cosmetic damage, antennas, AC cords, cabinets, headbands, ear-pads, or damage due to line power surges, connection to improper voltage supply or settings, misuse, mishandling, accident, acts of God or attempted repair by an unauthorized service agent.

To obtain service, the purchaser MUST present an original sales receipt / proof of purchase. Please contact us at www.ithomeproducts.com to request an RMA (Return Material Authorization) number to return products for service or replacement. Returns without an RMA number on the package will be refused and returned to sender. Upon receipt of the returning item and our full inspection (IT) may issue a replacement to customer for the same item or of one that has equivalent value and features. To return an item, supply full name, return address, phone number, item purchased, receipt of purchase and reason for return to obtain RMA number. All returns must be in the original packaging or reasonable substitute to prevent damage. Customer “Must” include full name, shipping address and telephone number inside of package. No return will be shipped back to a PO Box or APO address. Please include your check or money order in the amount of:

- **USD\$5.00 for items \$10.00 to \$39.99 (Price Paid Per Unit)**
- **USD\$10.00 for items \$40.00 to \$99.99. (Price Paid Per Unit)**
- **USD\$16.00, for items \$100.00 and up. (Price Paid Per Unit)**
- **Shipping fees are non-refundable**

to be payable to Innovative Technology Electronics Corp. (for handling and return shipping charges) (IT) will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any / all of the necessary information. Send all inquiries or RMA request via our website **www.ithomeproducts.com/support**.

Innovative Technology Electronics Corp.
1 Channel Drive, Port Washington, NY 11050
Toll free: 1-877-483-2497

Website for support: www.ithomeproducts.com/support

There are no express warranties except as listed above. REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER, (IT) SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Made in China.