

WALL PANIC ALARM

INSTALLATION AND OPERATING INSTRUCTIONS

Please keep these instructions in a safe place for future reference.

Kit contents:

- 1 x Panic alarm complete with 7" ripcord for activation
- 1 x Panic alarm holder
- 3 x Screws and wall plugs
- 1 x Instruction leaflet

1. Introduction

The Wall Panic alarm is a convenient highly visible security device which is ideal for use in the home or office. Its powerful 100dB siren and bright flashing red light are immediately activated when the ripcord is pulled, yet it can easily be deactivated using the switch on the side of the unit.

2. Battery installation

The Wall Panic Alarm requires 2 x AAA alkaline batteries (not included)

To install batteries:

- Unscrew the battery compartment cover and remove (See Fig.1)
- Insert 2 x AAA alkaline batteries noting the polarity diagram inside the compartment (see Fig. 2)
- Replace the cover and screw closed




Fig.1




Fig.2

IMPORTANT:

- Remove batteries before storing the alarm for long periods of time. Batteries corrode over time and may cause permanent damage to the unit.
- Different types of batteries or new and old batteries should not be mixed
- Depleted batteries should be removed from the

3. Battery testing

- It is recommended that the alarm power is regularly tested by pressing the battery test button on the front of the alarm or discreetly activating the alarm
- When the alarm siren weakens or the battery test indicates low batteries, replace with new batteries

4. Mounting the Panic Alarm to the wall

- Select the location where you wish the Panic Alarm to be fixed
- Use the panic alarm holder to mark the position of the 3 screws to be used to secure it
- Drill holes in the 3 marked positions and insert wall plugs provided
- Place the holder on the wall and secure into the 3 wall plugs with the screws provided
- Place the alarm unit in the holder, ensuring the ripcord is pulled through the hole at the base of the holder

5. Operation

- Push the ON/OFF switch up to the ON position to arm the alarm (Fig.3). The red LED will flash every 30 seconds to indicate that the unit is armed.
- To activate the alarm simply pull downwards on the ripcord, separating it from the alarm unit (Fig.4). The powerful 100dB siren will sound and the red LED light will flash continually
- To stop the alarm, push the switch to the OFF position and replace the ripcord pin into the alarm
- To deactivate the alarm, ensure the ripcord pin is replaced in the unit, and push the ON/OFF switch to the OFF position




Fig.3




Fig.4

6. Care & maintenance

To clean the unit housing, use a soft cloth slightly dampened with water, and wipe dry. Do not use chemical agents as this may damage and discolour the unit

WARNING: RISK OF PERSONAL INJURY
PROLONGED EXPOSURE TO THE ALARM SIREN MAY CAUSE
PERMANENT HEARING LOSS
FOR INDOOR USE ONLY
DO NOT USE IN WET LOCATIONS

Innovative Technology Electronics Corp.
Limited Warranty: 90 Days Labor, One Year Parts

Innovative Technology Electronics Corp. (IT) warrants the product to be free from "Defects" in materials under normal use for a period of "One Year" from the date of the original purchase. The Warranty is "Not" transferable. IT agrees, within the initial "90 Day" period, to repair or replace the product if it is determined to be defective at "No Charge". It is further agreed that IT will cover the cost to repair or replace damaged "Parts" only for a total period of "One Year" from the date of the original purchase. The warranty does not cover cosmetic damage, antennas, AC cords, cabinets, headbands, ear-pads, or damage due to line power surges, connection to improper voltage supply or settings, misuse, mishandling, accident, acts of God or attempted repair by an unauthorized service agent. **To obtain service, the purchaser MUST present an original sales receipt / proof of purchase. Please contact us at www.ithomeproducts.com to request an RMA (Return Material Authorization) number to return products for service or replacement.** Returns without an RMA number on the package will be refused and returned to sender. Upon receipt of the returning item and our full inspection (IT) may issue a replacement to customer for the same item or of one that has equivalent value and features. To return an item, supply full name, return address, phone number, item purchased, receipt of purchase and reason for return to obtain RMA number.

All returns must be in the original packaging or reasonable substitute to prevent damage. Customer "Must" include full name, shipping address and telephone number inside of package. No return will be shipped back to a PO Box or APO address. Please include your check or money order in the amount of

- **USD\$5.00 for items \$10.00 to \$39.99 (Price Paid Per Unit)**
- **USD\$10.00 for items \$40.00 to \$99.99. (Price Paid Per Unit)**
- **USD\$16.00, for items \$100.00 and up. (Price Paid Per Unit)**
- **Shipping fees are non-refundable**

to be payable to Innovative Technology Electronics Corp.(for handling and return shipping charges) (IT) will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any / all of the necessary information. Send all inquiries or RMA request via our website www.ithomeproducts.com/support.

Innovative Technology Electronics Corp.
1 Channel Drive
Port Washington, NY 11050
Toll free: 1-877-483-2497

Website for support: www.ithomeproducts.com/support

There are no express warranties except as listed above. REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER, (IT) SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

This Class [B] digital apparatus complies with Canadian ICES-003.