

## Mode d'emploi ITHW-858

Le casque d'écoute sans fil ITHW-858 est conçu pour les utilisateurs d'ordinateurs et d'autres appareils audiovisuels qui souhaitent écouter ce que bon leur semble en tout confort sans déranger les autres.


### Fonctions :

Fonction d'écoute sans fil :


Le signal audio traverse les murs, les plafonds et les autres obstacles. Le signal audio est transmis sans fil. Le produit est compatible avec les téléviseurs, les lecteurs de CD vidéo, les lecteurs de DVD, les ordinateurs et les autres appareils audio.

## Composantes


### 1. Émetteur



### 2. Récepteur



### 3. Accessoires



## Mode d'emploi

### 1. Fonction d'écoute sans fil

#### ■ Réglage de l'émetteur

Pour alimenter l'émetteur, insérez 3× piles AAA en observant les marques de polarité dans le compartiment à piles, ou utilisez un adaptateur CA 5 V-150 mA.

Mettez l'émetteur en marche et le voyant d'alimentation à DEL s'allumera. Pour écouter la télévision, insérez les fiches 2 et 3 dans la prise de sortie audio du téléviseur, insérez la fiche 1 dans l'émetteur et réglez le volume comme il convient. Pour écouter les sons de


votre ordinateur ou d'un quelconque autre appareil audio, branchez le câble 1 sur l'adaptateur 1, puis branchez la fiche 1 sur l'émetteur et la fiche 4 sur la prise d'écouteur ou sur la prise de sortie audio ; réglez le volume comme il convient.

#### ■ Réglage du récepteur

Pour alimenter le récepteur, installez 2 × piles AAA en observant la polarité indiquée sur le compartiment à piles.

A) Allumez le récepteur et réglez le volume comme il convient.

B) Appuyez sur le bouton RESET (Réinitialisation) et tenez-le enfoncé une seconde, puis appuyez sur le bouton SCAN (Balayage), et tenez-le enfoncé une seconde. Si la connexion est convenablement établie entre l'émetteur et le dispositif audio, vous entendrez le signal émis par l'émetteur. Vous pouvez appuyer sur les boutons de réinitialisation et de balayage à autant de reprises qu'il faut pour obtenir la qualité de son qui vous convient.



### 3. Éteindre

Lorsque vous avez terminé d'utiliser le casque, éteignez l'émetteur et le récepteur. Retirez les piles et débranchez les câbles si vous prévoyez ne pas utiliser l'appareil pendant une longue période de temps.

## Caractéristiques techniques principales

#### A : Émetteur

Compatible avec les lecteurs de CDV/DVD/CD, les PC et les autres dispositifs audiophoniques.

Fréquence de réception portée : 49,86 MHz

Mode de modulation : FM

Rayon de transmission sans obstacle : 30 mètres (Certains types d'obstacles, tels que les murs d'acier, réduisent radicalement l'étendue de la transmission.)

Alimentation : 4,5 V CC, courant statique inférieur à 20 mA

3 × piles AAA (NON COMPRISSES) ou adaptateur CA 5 V-150 mA.

#### B : Récepteur

Plage de fréquences de réception : 49,86 MHz.

Mode de réception : FM

Alimentation : 3 V CC, courant statique inférieur à 20 mA

2 × piles AAA (NON COMPRISSES)

Remarques : Veuillez prolonger les câbles audio et l'antenne pour améliorer les performances du système.

## Guide de dépannage

Problème	Causes possibles	Solutions
Le signal audio n'est pas reçu	L'émetteur n'est pas sous tension	Allumez l'émetteur.
	L'émetteur n'est pas convenablement branché sur la chaîne audio	Branchez l'émetteur et la chaîne audio convenablement.
	Le récepteur est à l'extérieur du rayon de transmission	Installez le récepteur à portée de transmission de l'émetteur.
Bruit	Les piles de l'émetteur ou du récepteur sont épuisées.	Remplacez les piles usées par des piles neuves.
	Le signal audio de votre chaîne audio est trop fort ou trop faible.	Réglez le volume de votre chaîne audio.
Mauvaise réception du signal audio	Les piles de l'émetteur ou du récepteur sont épuisées.	Remplacez les piles usées par des piles neuves.
	Le récepteur se déplace trop rapidement.	Ralentissez ou cessez de déplacer le récepteur.

Innovative Technology Electronics Corp.

Garantie limitée : 90 jours pour la main-d'oeuvre, un an pour les pièces  
Innovative Technology Electronics Corp. (IT) garantit que ce produit est exempt de « défauts » dans les pièces dans des conditions normales d'utilisation pendant une période « d'un an » à partir de la date originale d'achat. La garantie n'est pas transférable. IT consent, durant la période initiale de « 90 jours », à réparer ou à remplacer le produit « sans frais » si celui-ci est jugé défectueux. IT consent de plus à acquitter les frais de réparation ou de remplacement des « pièces » endommagées pendant une période « d'un an » à partir de la date originale d'achat. La garantie ne couvre pas les dommages cosmétiques, les antennes, les cordons CA, les boîtiers, les bandeaux, les cacheoreilles, ou les dommages causés par les sautes de puissance, le raccordement incorrect à une source d'alimentation ou à des réglages inadéquats, l'usage impropre, la manipulation inappropriée, un accident, une catastrophe naturelle ou une tentative de réparation par un prestataire de service non agréé.

Pour obtenir des prestations de service, l'acheteur DOIT soumettre un coupon original / une preuve d'achat.  
S'il vous plaît contactez-nous à [www.ithomeproducts.com](http://www.ithomeproducts.com) de demander un numéro RMA (Return Material Authorization) le numéro à retourner les produits pour réparation ou remplacement. Les retours sans numéro de RMA sur le paquet seront refusés et renvoyés à l'expéditeur. Dès réception de produit retourné et de notre inspection complète (IT) peut délivrer un remplacement au client pour le même article ou de celui qui a une valeur équivalente et de caractéristiques. Pour retourner un produit, fournissez le nom complet, adresse de retour, le numéro de téléphone, produit acheté, le coupon d'achat et la raison du retour pour obtenir le numéro de RMA. Tous les retours doivent être dans leur emballage original ou un autre emballage semblable pour éviter tout dommage. Vous devez indiquer votre nom, votre adresse d'expédition et votre numéro de téléphone. Aucun retour ne sera renvoyé à une boîte postale ou une adresse APO.

S'il vous plaît inclure votre chèque ou mandat-poste au montant de  
\$ 5,00 USD pour les articles de 10,00 \$ à \$ 39,99 (Prix Payé Par Unité)  
\$ 10,00 USD pour les articles de 40,00 \$ à \$ 99,99 (Prix Payé Par Unité)  
\$ 16,00 USD pour les articles de 100,00 \$ et plus (Prix Payé Par Unité)

Les frais de livraison sont non remboursables

d'être payable à Innovative Technology Electronics Corp. pour acquitter les frais de manutention et de retour. (IT) ne sera pas responsable pour des retards ou demandes non traitées résultant de la défaillance d'un acheteur de fournir tout ou partie des informations nécessaires.

Envoyez toutes les demandes ou des demandes de RMA via notre site [www.ithomeproducts.com / support](http://www.ithomeproducts.com/support).

Innovative Technology Electronics Corp. 1 Channel Drive  
Port Washington, NY 11050 Toll free: 1-877-483-2497

Website for support: [www.ithomeproducts.com/support](http://www.ithomeproducts.com/support)

(IT) NE SERA PAS RESPONSABLE POUR TOUT DOMMAGES OU DOMMAGES CONSÉCUTIFS À LA VIOLATION DE TOUTE GARANTIE EXPRESSE OU IMPLICITE SUR CE PRODUIT, SAUF DANS LA MESURE INTERDITE PAR LA LOI APPLICABLE. TOUTE GARANTIE IMPLICITE DE QUALITÉ MARCHANDE OU D'ADÉQUATION À UN USAGE PARTICULIER DE CE PRODUIT EST LIMITÉE EN DURÉE À LA PÉRIODE DE CETTE GARANTIE.

Certains états ne permettent pas l'exclusion ou la limitation des dommages fortuits ou consécutifs, ou les limitations sur la durée d'une garantie implicite, les exclusions ou limitations ne s'appliquent pas à vous. Cette garantie vous donne des droits légaux spécifiques et vous pouvez également avoir d'autres droits, qui varient d'un État à l'autre.



# VHF Wireless Headphones Casque d'écoute sans fil VHF

ITHW-858



Operation Manual

## IMPORTANT NOTES:

Be sure to turn off the headset after use to avoid draining the battery.

- To avoid injury to your ears, lower the volume level before putting on the headphones.
- Avoid listening at high volume for long periods of time.
- Do not listen to headphones while cycling, driving a vehicle, or operating machinery.

**FCC Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance will void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class C digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Move the transmitter to a different physical location.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your headphones.

## CALIFORNIA PROP 65 WARNING

"WARNING" This product contains a chemicals known to the State of California to cause birth defects or other reproductive harm. For more information on these regulations and a list of chemicals, log on the following website address:

<http://www.oehha.ca.gov/prop65.html>


ITHW-858 wireless headphone is designed for TV and other audio/video devices' users who would like to enjoy the listening silently without disturbing others

## Functions:


Wireless Listening:

The audio signal can go through walls, ceilings and other obstacles. The audio signal is transmitted wirelessly. The set is compatible with TV/VCD/DVD/PC and other audio devices.

## 2、Receiver



## 3、Accessories



## User's manual:

### Wireless Listening

#### ■ Transmitter adjustment

For the transmitter, mount 3× AAA batteries according to the engraved polarities in the battery case, or use the external 5V/150mA AC adapter .

A: When you listen to TV, put the plug ② and ③ in the audio-out jack of TV, put plug ① to transmitter and set the volume in proper status. When you listen to PC or other audio device, connect cable 1 and adapter 1, then put plug ① to transmitter and plug ④ to earphone jack or audio out jack, and operate the volume of audio device properly.


B: Switch on the transmitter, the power indicator LED will be on.

#### ■ Receiver adjustment


For the receiver, mount 2×AAA batteries as polarities instruction engraved in the battery case.

A: Switch on the receiver, adjust the volume properly.

B: Press the RESET button and hold one second, then press the SCAN button, and hold one second, if the connection between the transmitter and the audio device is correct, you can receive the signal sent out from the transmitter. You can repeat pressing the RESET and SCAN buttons again and again, until the effect is perfect.




Connect to the Audio-out of TV



Connect to the Audio-out jack of VCD/DVD



Connect to the earphone jack of CD



Connect to the speaker jack of PC

## Turn off

After using, turn off the transmitter and receiver. Take out the batteries and disconnect the cables when not use for a long time.

## Main Technical Parameters

### A: Transmitter

Compatible with TV, VCD, DVD, CD, PC and any other audio devices.

Transmission frequency: 49.86MHz

Modulation Mode: FM.

Transmission distance without obstacle: 30meters.(Certain type of obstacles such as steel walls, will reduce the transmission range drastically.)

Power: DC 4.5V, static current is less than 25mA.

3× AAA batteries (NOT INCLUDED) or 5V/150mA AC adapter.

### B: Receiver

Receiving frequency range: 49~54 MHz.

Receiving Mode: FM.

Power: DC 3V, static current is less than 25mA.

2×AAA batteries(NOT INCLUDED).

**Notes: Please extend the audio cable and antenna to improve the performance.**

## Trouble Shooting

Phenomena	Causes	Eliminating Means
The audio signal can't be received	The power of the transmitter is not turned on.	Turn on the transmitter.
	The transmitter isn't connected with the audio set properly	Connect the transmitter and audio set properly.
	The distance of receiver is beyond the transmission range.	Receive the signal in the transmission range.
Noise	The power of batteries in the receiver/transmitter is too low.	Replace the old batteries with new ones.
	The audio signal from your audio set is too strong or too weak.	Adjust the volume of your audio set properly.
	Severe interference occurred in the AC power supply-line.	Power off the interferent, or use another AC power supply-line. Or relocate the AC adapter cord, the audio cable and antenna of the transmitter.
Difficult to receive the audio signal	The power of batteries in the receiver/transmitter is too low.	Replace the old batteries with new ones.
	The receiver is moved too quickly.	Slow down or stop moving the receiver

Innovative Technology Electronics Corp.

Limited Warranty: 90 Days Labor, One Year Parts

Innovative Technology Electronics Corp. (IT) warrants the product to be free from "Defects" in materials under normal use for a period of "One Year" from the date of the original purchase. The Warranty is "Not" transferable. IT agrees, within the initial "90 Day" period, to repair or replace the product if it is determined to be defective at "No Charge". It is further agreed that IT will cover the cost to repair or replace damaged "Parts" only for a total period of "One Year" from the date of the original purchase. The warranty does not cover cosmetic damage, antennas, AC cords, cabinets, headbands, ear-pads, or damage due to line power surges, connection to improper voltage supply or settings, misuse, mishandling, accident, acts of God or attempted repair by an unauthorized service agent.

**To obtain service, the purchaser MUST present an original sales receipt / proof of purchase. Please contact us at [www.ithomeproducts.com](http://www.ithomeproducts.com) to request an RMA (Return Material Authorization) number to return products for service or replacement.** Returns without an RMA number on the package will be refused and returned to sender. Upon receipt of the returning item and our full inspection (IT) may issue a replacement to customer for the same item or of one that has equivalent value and features. To return an item, supply full name, return address, phone number, item purchased, receipt of purchase and reason for return to obtain RMA number.

All returns must be in the original packaging or reasonable substitute to prevent damage. Customer "Must" include full name, shipping address and telephone number inside of package. No return will be shipped back to a PO Box or APO address. Please include your check or money order in the amount of

**USDS\$5.00 for items \$10.00 to \$39.99 (Price Paid Per Unit)**

**USDS\$10.00 for items \$40.00 to \$99.99. (Price Paid Per Unit)**

**USDS\$16.00, for items \$100.00 and up. (Price Paid Per Unit)**

**Shipping fees are non-refundable**

to be payable to Innovative Technology Electronics Corp. (for handling and return shipping charges) (IT) will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any / all of the necessary information.

Send all inquiries or RMA request via our website [www.ithomeproducts.com/support](http://www.ithomeproducts.com/support).

Innovative Technology Electronics Corp.

1 Channel Drive

Port Washington, NY 11050

Toll free: 1-877-483-2497

Website for support: [www.ithomeproducts.com/support](http://www.ithomeproducts.com/support)


There are no express warranties except as listed above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER. (IT) SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

## Component Part Instruction

### 1、Transmitter



1

2

3

4