

Push Button Instructions

Please read before using this product and test before placing lid on the keybox. Lid will not work if combination is set incorrectly. For greater security, please change combination periodically.

1. Selecting your combination

On the front of the keybox you will see buttons numbered 1 through 0. You will also see an OPEN button and a CLEAR button. There is no preset combination on your keybox. You will select your own combination. Keep the combination in a safe place. For best results, select between four and seven numbers in your combination. Each number can only be used one time. Do not use number combinations that can be easily guessed such as your phone number, vehicle licence plate or street address. Select a combination and record it in the blank diagram below labelled *Figure (b)*.

2. Setting your combination

WARNING! Improperly setting the combination is not covered under the warranty. Do not remove the screws on the back of the lid. Doing so will void the warranty. Press down on CLEAR then press down on OPEN button and pull out the lid.



Figure (b)

Remove the plastic card from the back of the lid by lifting from the center of the edges.

You will see ten numbered grey buttons with arrows. Turn the lid in your hand so the back is facing you and the number "1" is in the upper left corner of the lid as shown in diagram labelled *Figure (d)*. These numbers correspond to the numbered buttons on the front of the lid. All the arrows on the screws point to the left because there is no preset combination. Arrows pointing to the left are not part of combination.

Use the screwdriver tip on the plastic card or a small screwdriver to push and rotate the arrows. For each number in your combination apply light pressure and rotate a half turn so that the arrow points to the right and snaps up. Arrows rotated a half turn to the right are set as part of your combination.

Check to make sure that the arrow of any number that is not in the combination is pointing LEFT.




Figure (d)

CAUTION: Arrows must point either to the **left** or to the **right**. An arrow pointing to the **left** is not a number in the combination. An arrow pointing to the **right** is a number in the combination. If any arrow is pointing **up, down** or has **not snapped up**, the combination **will not work**.

Replace the plastic card on the back of the lid. Place up to 2 keys on the key clip

3. Testing your combination (Test the combination before putting the lid on the keybox).

On the front of the lid push in the numbered buttons that are in your combination. Press down on the OPEN button. If the combination is SET CORRECTLY, the open button will slide down fully. If the combination was SET INCORRECTLY, the open button will not slide down. If set incorrectly DO NOT RETURN THE LID TO THE KEYBOX. Press the CLEAR button and refer back to section 2. Setting your combination.

4. Mounting your Keybox

- Remove the lid
- Find a convenient flat surface
- Mount with screws
- Replace the lid

5. Opening and using your Keybox (once your combination has been set)

Push in the buttons that correspond to the combination you have just set. Buttons may be pushed in any order.

Push down the OPEN button and while holding it down pull the lid out from the keybox. If you have entered an incorrect combination you can return the buttons to their original setting by sliding down the CLEAR button. When you release the OPEN button the combination will clear.

To replace the lid, push in the buttons that correspond to the combination you have set. Place the lid into the keybox by first setting the bottom of the lid into the vault. Push down and hold the OPEN button as you return the lid to the closed position. The lid will lock into place and the combination will clear when the OPEN button is released.

Warranty

Innovative Technology Electronics Corp.
Limited Warranty: 90 Days Labor, One Year Parts

Innovative Technology Electronics Corp. (IT) warrants the product to be free from "Defects" in materials under normal use for a period of "One Year" from the date of the original purchase. The Warranty is "Not" transferable. IT agrees, within the initial "90 Day" period, to repair or replace the product if it is determined to be defective at "No Charge". It is further agreed that IT will cover the cost to repair or replace damaged "Parts" only for a total period of "One Year" from the date of the original purchase. The warranty does not cover cosmetic damage, antennas, AC cords, cabinets, headbands, ear-pads, or damage due to line power surges, connection to improper voltage supply or settings, misuse, mishandling, accident, acts of God or attempted repair by an unauthorized service agent.

To obtain service, the purchaser MUST present an original sales receipt / proof of purchase. Please contact us at www.ithomeproducts.com to request an RMA (Return Material Authorization) number to return products for service or replacement. Returns without an RMA number on the package will be refused and returned to sender. Upon receipt of the returning item and our full inspection (IT) may issue a replacement to customer for the same item or of one that has equivalent value and features. To return an item, supply full name, return address, phone number, item purchased, receipt of purchase and reason for return to obtain RMA number.

All returns must be in the original packaging or reasonable substitute to prevent damage.

Customer "Must" include full name, shipping address and telephone number inside of package. No return will be shipped back to a PO Box or APO address.

Please include your check or money order in the amount of

- **USD\$5.00 for items \$10.00 to \$39.99 (Price Paid Per Unit)**
- **USD\$10.00 for items \$40.00 to \$99.99. (Price Paid Per Unit)**
- **USD\$16.00, for items \$100.00 and up. (Price Paid Per Unit)**
- **Shipping fees are non-refundable**

to be payable to Innovative Technology Electronics Corp.(for handling and return shipping charges) (IT) will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any / all of the necessary information. Send all inquiries or RMA request via our website www.ithomeproducts.com/support.

Innovative Technology Electronics Corp.
1 Channel Drive
Port Washington, NY 11050
Toll free: 1-877-483-2497

Website for support: www.ithomeproducts.com/support

There are no express warranties except as listed above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE

REMEDY OF THE CUSTOMER, (IT) SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR

CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF

MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.